



Fiberglass Pipe Installation Guide – Water Lube

478-279-2606

Handle with care. As the name implies, this is a **glass** product so please handle with respect. If product is dropped or damaged and “white spots” appear, contact Universal Fiberglass because the integrity of the product has been compromised and will need to be replaced.

Place the Brass/Stainless/Neoprene retainer over shaft and push it down in the coupling so it sits against the fiberglass pipe. Then apply **Chesterton 785 anti-seize** to threads on the stainless steel adapter and inside pipe coupling to help prevent galling. Next start the pipe into the coupler. Place the back-up wrench on the coupling and the tightening wrench on the stainless adapter above the threads. **“Never place a chain wrench directly on the fiberglass”** Screw the adapter into the coupling until you feel it butt up to the retainer, then tighten just a bit more. (We recommend a Ridged WA36 or smaller chain wrench for tightening pipe. **(Don’t use cheater bars or wrenches for tightening pipe.)**)